

REPLACEMENT PARTS GUIDE

L110 Lawn Tractor with 42 inch Deck

ENGINE

SPARK PLUG
[M78543](#)
Change Every 50/100/150/200/250 Hrs.

ENGINE OIL FILTER
[AM125424](#)

ENGINE OIL
[TY22029](#) (Turf Gard™ 10W30)
(WITHOUT OIL FILTER - 1.8L(1.9 qt))
(WITH OIL FILTER - 1.9L(2 qt))
Change Every 50/100/150/200/250 Hrs.

HEADLIGHT BULB
[AD2062R](#)

FUEL FILTER-IN-LINE
[AM116304](#)
Change Every 50/100/150/200/250 Hrs.

AIR FILTER
[GY20661](#)
Change Every 50/100/150/200/250 Hrs.

HOME MAINTENANCE KIT
[LG240](#)

MULTI- PURPOSE SD POLYUREA GREASE
[TY6341](#)

GREASE GUN
[TY26183](#)
Change Interval:As needed.

MOWER DECK

MOWER BLADE
[GX20433](#) (HIGH LIFT)

MOWER DECK LEVELLING GAUGE
[AM130907](#)



FUEL AND AIR

FUEL TANK FILLER CAP
[GX22166](#)

MUFFLER
[AM138423](#)

ELECTRICAL

ROTARY SWITCH
[GY20074](#)

PLUNGER SWITCH
[GY20094](#)

REVERSE IMPLEMENT PUSH SWITCH
[AM124734](#)

TRACTION DRIVE BELT
[UC30568](#)

KEY
[GY20680](#)

BATTERY
[TY25221B](#) (12 V) (FOR CANADA AND USA)
[MCYP340PE](#) (12 V) (NOT FOR CANADA AND USA)

CONTROL LEVER THROTTLE CABLE
[GY20625](#)

MOWER DECK

GAGE WHEEL
[GX10168](#)

FLAT MOWER BELT
[GX20072](#) (LGTH = 2635 mm,
WIDTH = 12.7 mm, TK = 8.89 mm)