

REPLACEMENT PARTS GUIDE

CS770 Cotton Stripper (S.N. - 248999)

CAB



FRESH AIR FILTER

[RE284091](#)

Clean or replace every 50 hours or as required. If operating in dusty conditions clean daily.

RECIRCULATION AIR FILTER

[AXE70605](#)

Clean or replace every 250 hours or as required. If operating in dusty conditions clean daily.

ENIGNE

DIESEL EXHAUST FLUID DOSING FILTER

[DZ114640](#)

Replace after first 1500 hours or 3 years, whichever occurs first.

FUEL PRECLEANER FILTER

[R502778](#)

Replace every 400 hours or annually, whichever occurs first.

DEF BREATHER

[H216169](#)

Replace every 2000 hours.

PRIMARY AIR FILTER

[HXE11090](#)

Replace every 400 hours or annually, whichever occurs first.

SECONDARY AIR FILTER


[HXE11091](#)

Replace every 400 hours or annually, whichever occurs first.

DIESEL EXHAUST FLUID IN-LINE FILTER

[DZ110513](#)

Replace after first 1500 hours or 3 years, whichever occurs first.



ENIGNE

OIL FILTER

[RE572785](#)

Minimum hours before first engine oil change is 100 hours. Extended engine oil change every 375 hours or annually, whichever come first. The extended 375 hour interval is only allowed if using Plus-50™ II oil with a John Deere filter and diesel fuel with sulfur content less than 15mg/kg (15ppm). If all conditions are not met, change oil and filter at 250 hours of operation.



PRIMARY FUEL FILTER

[DZ124761](#)

Replace every 400 hours or annually, whichever occurs first.



SECONDARY FUEL FILTER

[DZ124786](#)

Replace every 400 hours or annually, whichever occurs first.



HYDRAULICS

AUXILIARY GEAR CASE OIL FILTER

[AKK28711](#)

Replace every 1000 hours.

CHASSIS RETURN OIL FILTER

[AKK33523](#)

Replace every 1000 hours.

PUMP FILTER

[AKK43338](#)

Replace every 1000 hours.

PROPEL PUMP CHARGE FILTER

[RE273801](#)

Replace every 1000 hours.



CAPACITIES

CS770 Cotton Stripper (S.N. - 248999)

CAPACITIES (Approximate):

Fuel Tank:

..... 1022 L (270 gal)

Diesel Exhaust Fluid Tank:

John Deere Diesel Exhaust Fluid™

Final Tier 4 / Stage IV and Stage V 104.4 L (27.5 gal)

Auxiliary Water Tank:

John Deere Spindle Cleaner™

..... 257 L (68 gal)

Cooling System:

Cool-Gard™ II

Final Tier 4 / Stage IV and Stage V 68.1 L (18 gal)

Engine Crankcase (Includes Filter):

Plus-50™ II

Final Tier 4 / Stage IV and Stage V 56.7 L (15 gal)

Hydraulic Oil Reservoir:

Hy-Gard™

..... 113.5 L (30 gal)

Hydraulic and Hydrostatic System:

Hy-Gard™

..... 216 L (57 gal)

Final Drive: (2 Used)

GL-5

Standard Capacity 7.8 L (2 gal)

High Capacity 23 L (6.1 gal)

Row Unit Gear Case: (6 Used)

Hy-Gard™

..... 25 L (6.6 gal)

Rear Axle Main Body Housing:

GL-5

..... 9.9 L (2.6 gal)

Rear Axle Auxiliary Gearbox:

GL-5

..... 1.3 L (0.34 gal)











Rear Axle Planetary: (2 Used)

GL-5








..... 3.8 L (1 gal)

REPLACEMENT PARTS GUIDE

CS770 Cotton Stripper (S.N. - 248999)

	SPRING TENSION FEEDER BELT AKK32901 Prevents belt slippage, easier to set tension.
	CLEANER & FEEDER PADDLE AKK36512
	CLEANER & FEEDER AUGER AKK43730
	CLEANER DOFFER ASSEMBLY AKK23874
	CLEANER DOFFER BRUSH AKK23868
	CLEANER SAW ASSEMBLY AKK51674
	CLEANER SAW SEGMENTS N221590
	CLEANER SAW BEARINGS AN220646
	SPHERICAL BALL BEARING JD8673
	CLEANER CLUTCHES N221611 N221993 N125300



	ROLLER BRUSH KK72056
	ROLLER BRUSH RETAINER KK26412
	ROUND MODULE BELT PIN KK36931
	ROUND MODULE BELTS AKK29500 AKK29499
	GROOVED WRAP ROLLER AKK22228 Reduce wrap misfeeds caused by wrapping rear roller.
	CLEANER DRIVE V BELT N117398 N33746 M91270
	CYLINDRICAL BALL BEARING AN272787

REPLACEMENT PARTS GUIDE

CS770 Cotton Stripper (S.N. - 248999)



LH AND RH RETAINER
[N125408](#)



AUGER
[AN221692](#) (RH)
[AN221693](#) (LH)



CROP GUIDES SUPPORT
[AKK26977](#) (RH)
[AKK26976](#) (LH)



CROP GUIDES SHOE
[N220836](#) (RH)
[N220837](#) (LH)



CROP GUIDES STRAP
[N220186](#)



CROP GUIDES BAR
[N221256](#) (RH)
[N221257](#) (LH)



HEIGHT SENSING ROD
[N223457](#)



SECTION V BELT
[KK66252](#)



LH AND RH BAT/FLAP
[AN123821](#)



JOHN DEERE
Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.