

FILTER OVERVIEW WITH SERVICE INTERVALS AND CAPACITIES

4930 Self-Propelled Sprayer

ENGINE

SECONDARY AIR FILTER – [RE210103](#)

Replace after every second Primary Air Filter change.

ENGINE

PRIMARY AIR FILTER – [RE210102](#)

Replace filters at least once a year or if air filter indicator remains ON.

ENGINE

OIL FILTER – [RE509672](#)

Initial Oil Filter change is at 100 engine hours; then every 250 engine hours thereafter. Refer to the OM for special note regarding extended drain intervals.

If PLUS-50 oil and a John Deere filter are used regular interval can be extended to 375 hours.

(Click here for [capacity](#))

ENGINE

FUEL FILTER KIT – [RE525523](#)

Replace after every 500 engine hours.

ON BOARD AIR (OBA)

AIR DRYER CARTRIDGE – [AN204967](#)

Replace annually.

CAB

AIR FILTER ACTIVATED CARBON – [RE199681](#)

Replace after every 500 engine hours or annually, whichever comes first.

CAB

AIR FILTER RECIRCULATION ACTIVATED CARBON – [RE199682](#)

Do not clean filter. Replace filter at service interval or when performance indicates.

HYDRAULICS

OIL FILTER – [AH128449](#)

Replace after every 500 engine hours.

(Click here for [capacity](#))

HYDROSTATIC DRIVE

OIL FILTER – [AN207368](#)

Replace after every 500 engine hours.

(Click here for [capacity](#))



JOHN DEERE

Genuine Parts and Service

CAPACITIES

4930 Self-Propelled Sprayer

CAPACITIES (Approximate):

Fuel Tank:

..... 534 L (141 gal)

Cooling System with Heater:

Cool-Gard™ II

..... 40 L (10.6 gal)

Crankcase including Filter:

Plus-50™ II

..... 31 L (8.2 gal)

Hydraulic Reservoir:

Torq-Gard™ Supreme

..... 76 L (20 gal)

Hydraulic System:

Torq-Gard™ Supreme

Hydraulic and Hydrostatic..... 35.8 L (9.5 gal)

Final Drives (Front Hubs) Each:

GL-5

..... 3.8 L (1 gal)

Final Drives (Rear Hubs) Each:

GL-5

..... 3.8 L (1 gal)

[Return to Filter Overview](#)

