

# REPLACEMENT PARTS GUIDE

## 3046R Tractor (PIN: 1LV3046R\*\*L\*00001- ) (Worldwide Edition)

### ENGINE



#### ENGINE OIL

[TY26668](#) (John Deere Plus-50™ II Premium)  
(10W-30) (5.7 L (1.5 gal)) (WITH FILTER)

Change every 400 hrs/ Annually




#### SPIN-ON FUEL FILTER

[MIA882963](#) (FILTER KIT)

[MIU803127](#) (FILTER ELEMENT)

Change after every 400 Hrs/Annually.



#### AIR FILTER

[RE68048](#) (PRIMARY)

[RE68049](#) (SECONDARY)

Change every 600 hrs. or annually.



#### JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY24416](#)

GREASE GUN

[TY26183](#)

Change As Required.



#### OIL FILTER

[M806419](#)

Change Every 200 Hrs or Annually, whichever comes first.



#### FUEL-WATER SEPARATOR

[MIA885324](#) (FILTER KIT)

[MIU802421](#) (FILTER ELEMENT)

Change after every 400 Hrs. or annually.



#### FILTER PAK

[TA25768](#)



#### DIESEL PARTICULATE FILTER

[MIU803232](#)

### AXLE



#### TIE ROD

[LVA19527](#) (MFWD)

[LVA10747](#) (SCV, BOOM LINKAGE, OOS)

[LVA10748](#) (SCV, BUCKET LINKAGE, OOS)



#### FRONT AXLE OIL

[TY22062](#) (John Deere Hy-Gard™)  
(4.8 L (1.3 gal.))

Change every 50/400/600 Hrs.



### ELECTRICAL

#### KEY

[RE183935](#)

#### ROTARY SWITCH

[LVA21501](#) (14 V)

#### WET DISCHARGE BATTERY

[TY27831B](#) (12 V, 45 AH)

#### LED WORK LIGHT

[AM143579](#) (OOS) (12 V)

#### HEADLIGHT

[TA24237](#) (RH, WORK LAMP)

[TA24236](#) (LH, WORK LAMP)

[R136239](#) (BULB, 12 V)

#### V - BELT

[TR131486](#) (FOR ALTERNATOR) (75 A)  
(LGTH = 1112 mm)

### FUEL TANK FILLER CAP

#### FILLER CAP

[AL213202](#)

### CAB (IF EQUIPPED)

#### AIR FILTER

[MIU10010](#) (FRESH)

[MIU10011](#) (RECIRCULATION)

Service or Change every 50 hrs.

### TRANSMISSION/ HYDRAULIC

#### TRANSMISSION/HYDRAULIC OIL

[TY22062](#) (John Deere Hy-Gard™)  
(25.7 L (6.8 gal.))

Change every 400 hrs.

#### OIL FILTER

[LVA23443](#) (FRONT PTO FILTER)

[LVA13065](#) (HYDRAULIC SUCTION FILTER ELEMENT)

Change every 400 hrs.