

# REPLACEMENT PARTS GUIDE

## 4044R Compact Utility Tractor

### ENGINE



#### ENGINE OIL

[TY26668](#) (10W-30 PLUS-50™ II),  
5.4 L (1.4 gal.)

Change Every 200 Hrs or Annually, whichever comes first.



#### FUEL FILTER

[MIU803127](#)

Change after every 400 Hrs or Annually.



#### AIR FILTER

[RE68048](#) (PRIMARY)

[RE68049](#) (SECONDARY)

Change after every 600 hrs or Annually.



#### JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY6341](#)

GREASE GUN

[TY26183](#)

Change As Required.



#### OIL FILTER

[M806419](#)

Change Every 200 Hrs or Annually, whichever comes first.



#### FUEL-WATER SEPARATOR

[MIU803221](#) (SEPARATOR)



[MIU802421](#) (FILTER ELEMENT)

Change after every 400 Hrs or Annually.



#### DIESEL PARTICULATE FILTER

[MIU803276](#)



#### HOME MAINTENANCE KIT

[TA25765](#)

### AXLE

#### TIE ROD

[LVA14951](#) (ASSEMBLY)

[LVA14960](#) (LH)

[LVA14959](#) (RH)



#### FRONT AXLE OIL

[TY22000](#) (JOHN DEERE LOW VISCOSITY HY-GARD™)

Change every 50/400/600 Hrs.



### ELECTRICAL

#### KEY

[RE183935](#)



#### ROTARY SWITCH

[LVA21501](#)



#### BATTERY

[TY26442B](#) (12 V)



#### HEADLIGHT

[R136239](#) (12 V 60/55 W)



#### LED WORK LIGHT

[AM143579](#) (12 V) (OOS)



### FUEL AND AIR

#### FILLER CAP

[AL213202](#)



### TRANSMISSION/ HYDRAULIC

#### V - BELT

[TR131486](#) (LGTH = 1112 mm,  
WIDTH = 13.4 mm, TK = 9.6 mm)



#### TRANSMISSION/HYDRAULIC OIL

[TY22000](#) (47.3 L (12.5 gal.))

Change after every 400 Hrs or Annually.



#### OIL FILTER

[RE45864](#) (TRANSMISSION)

[LVA10419](#) (HYDRAULIC)

Change after every 400 Hrs or Annually.

