

# REPLACEMENT PARTS GUIDE

5 Series - 5045D (2WD), 5050D, 5205 Tractor (TREM IIIA Engine)



## ENGINE



**OIL FILTER**  
[RE507204](#)



**PRIMARY AIR FILTER**  
[RE68048](#)



**SECONDARY AIR FILTER**  
[RE68049](#)



**PRIMARY FUEL FILTER**  
[RE508953](#)



**SECONDARY FUEL FILTER**  
[RE508954](#)

## HYDRAULIC/ TRANSMISSION



**OIL FILTER**  
[RE45864](#)

Item	First 100 Hours	Every 250 Hours	Every 500 Hours	Annually
Engine Oil Filter	Replace	Replace		
Primary Air Filter Element				Replace
Secondary Air Filter Element				Replace
Primary Fuel Filter	Replace	Replace		
Secondary Fuel Filter	Replace		Replace	
Hydraulic-Transmission Oil Filter	Replace		Replace	



CLICK PART NUMBER TO BUY

\*See operator's manual for additional details.

# CAPACITIES

## 5 Series - 5045D (2WD), 5050D, 5205 Tractor (TREM IIIA Engine)

Machine Components	Part no.	Capacities (approx.)
Fuel Tank	<a href="#">SJ34318</a>	60 L
Engine Oil	<a href="#">PY10850</a> (8.5 L) <a href="#">PY10852</a> (6.5 L) <a href="#">PYS10129</a> (4 L) <a href="#">PY10851</a> (1 L)	8.5 L
Coolant (Cool-Gard™)	<a href="#">PY0747</a> (10 L) <a href="#">PYS10130</a> (5 L) <a href="#">PY0746</a> (1 L)	10 L
Transmission- Hydraulic Oil for Grease axle (John Deere Hy-Gard™)	<a href="#">PY0023</a> (20) <a href="#">PY0980</a> (5 L) <a href="#">PY0024</a> (1 L)	30 L
Transmission- Hydraulic Oil for Oil Axle (John Deere Hy-Gard™)	<a href="#">PY0023</a> (20 L) <a href="#">PY0980</a> (5 L) <a href="#">PY0024</a> (1 L)	32 L
Mechanical Front Wheel Drive (MFWD) Oil (John Deere Hy-Gard™)	<a href="#">PY0980</a> (5 L) <a href="#">PY0024</a> (1 L)	5.9 L
JD GREASE GARD PREMIUM	<a href="#">PYS10231</a>	200 gm
	<a href="#">PY10853</a>	5 KG



**JOHN DEERE**

Genuine Parts and Service

# REPLACEMENT PARTS GUIDE

## 5 Series - 5045D (2WD), 5050D, 5205 Tractor (TREM IIIA Engine)

### CAB



#### SEAT

- [SJ18538](#) (FIXED)(MANUAL STEERING)
- [RE73193](#) (BACK)
- [SJ18041](#) (BOTTOM)
- [SJ26883](#) (ADJUSTABLE)  
(POWER STEERING)
- [RE212692](#) (BACK)
- [RE73192](#) (BOTTOM)
- [SJ34660](#) (POWER STEERING)
- [PY11757](#) (SEAT COVER)



### BRAKE



#### BRAKE DISK

- [SJ18395](#) (Z = 14)
- [SJ18396](#) (Z = 16) (5045D)

### CONTROL VALVE



#### CONTROL VALVE

- [RE231804](#) (W/ FCV)
- [SJ34845](#) (W/ SCV)
- [SJ40343](#) (HITCH)
- [SJ34844](#) (STEERING)(HITCH)
- [SJ31687](#) (HITCH)
- [SJ34846](#) (W/O QRL)
- [SJ33024](#) (W/ EQRL)

### ENGINE



#### CLUTCH DISK

- [SJ29350](#) (FOR DUAL CLUTCH)
- [RE242274](#) (PTO)
- [SJ23064](#) (USE WITH RE229970)
- [SJ41472](#) (USE WITH SJ41473)



#### RADIATOR

- [SJ299385](#) (48 mm CORE)
- [SJ36339](#) (56 mm CORE) (5050D)



#### FAN DRIVE BELT

- [SU63793](#) (LGTH = 1340 mm)
- [R73784](#) (LGTH = 1340 mm) ( - 021554)
- [SU38901](#) (LGTH = 1300 mm)  
( 021555 - 028903)
- [SU64566](#) (LGTH = 1315 mm)  
(021555 - 028903)
- [SU63792](#) (LGTH = 1365 mm)

### OTHERS

#### QUICK LOCK PIN

- [SU20995](#) (ROCK SHAFT)
- [AR60372](#) (HITCH)
- [AR62149](#) (W/O QRL)

#### SWAY CHAIN

- [SJ24944](#)

#### FUEL TANK

- [SJ34318](#)

#### FENDER

##### LOW CLEARANCE

- [SJ41995](#) (RH) (5045D, 5050D)
- [SJ41994](#) (LH) (5045D, 5050D)

##### High CLEARANCE

- [SJ41999](#) (RH) (W/O ROPS)
- [SJ41998](#) (LH) (W/O ROPS)
- [SJ42571](#) (RH) (W/ ROPS) (5045D, 5050D)
- [SJ42570](#) (LH) (W/ ROPS) (5045D, 5050D)

#### TRACTOR COVER

- [PY11857](#)

### AXLE

#### TIE ROD

- [SJ14021](#) (MFWD)
- [SJ14025](#) (LH)
- [SJ14024](#) (RH)
- [RE234118](#) (MECHANICAL STEERING)  
( - 007319)
- [RE190481](#) (LH)
- [RE190506](#) (RH)
- [RE192255](#) (MECHANICAL STEERING)  
(007320 - )
- [RE190481](#) (LH)
- [RE190506](#) (RH)



**JOHN DEERE**  
Genuine Parts and Service

CLICK PART NUMBER TO BUY

\*See operator's manual for additional details.