

# REPLACEMENT PARTS GUIDE

## 5D Series - 5050D Tractor (TREM IIIA Engine) (India Edition)



### HYDRAULIC / TRANSMISSION



**OIL FILTER**  
[RE45864](#)

**ROCKSHAFT OIL FILTER**  
[SJ11062](#)

[RE280728](#)

Replace after initial 500 hours and change every 1100 hours and every 1250 hours.

### ENGINE



**OIL FILTER**  
[RE507204](#) (For India)  
[T19044](#) (For Export)

Change every 100 hours and 250 hours and annually.



**PRIMARY AIR FILTER**  
[RE68048](#)



**SECONDARY AIR FILTER**  
[RE68049](#)

Change after every 250 hours and annually.



**PRIMARY FUEL FILTER**  
[RE508953](#)  
[RE539502](#)



**FINAL FILTER**  
[RE508954](#)

Replace after every 250 hours.



**JOHN DEERE**  
Genuine Parts and Service

# CAPACITIES

## 5D Series - 5050D Tractor (TREM IIIA Engine) (India Edition)

### CAPACITIES (Approximate):

#### *Fuel Tank:*

..... 60 L (15.85 gal)

#### *Cooling System: Cool-Gard™ II*

..... 9.8 L (2.59 gal)

#### *Transmission and Hydraulic System: Hy-Gard™*

Grease Axle ..... 30 L (7.92 gal)

Oil Axle ..... 32 L (8.45 ga)

#### *Mechanical Front Wheel Drive (MFWD) Axle Housing: MFWD Differential Housing*

..... 5.92 L (1.55 gal)

# REPLACEMENT PARTS GUIDE

## 5D Series - 5050D Tractor (TREM IIIA Engine) (India Edition)

**ENGINE**

**CLUTCH DISK**  
[SJ29350](#) (DUAL)  
[RE242274](#) (PTO)  
[SJ23064](#) (SINGLE)

**BATTERY**  
[TY25879](#)

**BRAKE DISK**  
[SJ18395](#)

**FAN BELT DRIVE**  
[SU63793](#) (LGTH = 1340 mm)  
[SU38901](#) ( LGTH = 1300 mm)  
[SU64566](#) (LGTH = 1315 mm)

**ALTERNATOR**  
[RE258846](#)



**CAB**

**SEAT**  
[SJ34660](#) (ASSEMBLY)  
[RE73192](#) (BOTTOM)  
[RE212692](#) (BACK)  
[SJ26883](#) (POWER STEERING)  
[SJ18041](#) (BOTTOM)  
[RE73193](#) (BACK)

**AXLE**

**TIE ROD**  
[RE234118](#) (FRONT) (ASSEMBLY)  
[RE190506](#) (RH)  
[RE190481](#) (LH)  
[RE208624](#) (POWER STEERING )  
[SJ14021](#) (MFWD)  
[SJ14025](#) (LH)  
[SJ14024](#) (RH)  
[LVA14171](#)

