

TimberNavi™ Office Software Installation Instructions

February 2017



IMPORTANT: All steps need to be completed before using TimberNavi software on your computer.

Map Designer and TimberNavi Simulator Installation

It is mandatory to log into a computer with administrator credentials while running the installation and entering the license key.

NOTE: Use the troubleshooting section in the TimberNavi™ support website to assist with installation problems.

1. Log into MyJohnDeere.com.
2. Click the TimberNavi Jobsite Mapping link.
3. Check that your computer fulfils the hardware and software requirements described in System Requirements Document inside System & Software Requirements section on the TimberNavi website.
4. Go to the Downloads & Updates section.
5. Download the TimberNavi Map Designer and Simulator file.
6. Double-click downloaded file. This should start the installation wizard program.
7. Click **INSTALL** button to start the installation procedure.
8. Read through the Software License Agreement and accept.
9. After the installation wizard completes the installation click the **FINISH** button.
10. Computer restarts.
11. TimberNavi Map Designer and Simulator is now successfully installed on your computer.
12. Follow licensing steps below.

TimberNavi Map Designer and Simulator Licensing

Licensing your version of TimberNavi Map Designer and Simulator is required for the software to function beyond the trial period

1. Close TimberNavi Map Designer and the Simulator if it is open.
2. Open the License Tool program from the Start menu → Programs → John Deere → License Tool. If using Windows 10 go to Start menu → All Apps → John Deere → License Tool.
3. Check your computer's unique challenge key by pressing the **GET** button in the "Challenge key" section.
4. Copy the challenge key by pressing the **COPY** button in the "Challenge key" section.
5. Log into MyJohnDeere.com.

6. Click the TimberNavi site link.
7. Go to the Licensing Form section.
8. Paste the challenge key in the Challenge Key field and fill out other mandatory fields: Customer Name, Company Name, and your local John Deere Dealer. Press the **SEND** button to complete the request.
9. A John Deere representative will provide the license file to the email address entered into the form.
10. Save the XML license file to your PC.
11. Open the License Tool program again and click **OPEN LICENSE KEY FILE**.
12. Browse to the file location and click **OPEN**.
13. Click the **OK** button to save the license key onto your computer.
14. License tool opens a pop-up window telling that the license key was valid. Click the **OK** button to confirm.
15. You have now successfully licensed your TimberNavi Map Designer and Simulator software.

Add-in Toolbar Installation

ArcGIS™ for Desktop needs to be installed before installing the Add-in Toolbar.

1. Log into MyJohnDeere.com.
2. Click the TimberNavi site link.
3. Go to the Downloads and Updates section.
4. Download the TimberNavi Add-In Toolbar file.
5. Double-click downloaded file. This should start the installation wizard program.
6. Click **INSTALL ADD-IN**.
7. After the installation succeeds, click **OK**.
8. TimberNavi Add-in Toolbar is now successfully installed on your computer.
9. To turn toolbar ON inside ArcMap™, open ArcMap™ program.
10. Click Customize menu → Toolbars → 'TimberNavi Toolbar'.
11. Click Customize menu → ArcMap™ Options...
12. Inside the Options window, go to Sharing tab.
13. Add check mark to 'Enable ArcGIS™ Runtime Tools' under Packaging header.
14. TimberNavi Add-in Toolbar is ready to use.