# REPLACEMENT PARTS GUIDE

**3032E Compact Utility Tractor** 

## **ENGINE**



ENGINE OIL <u>TY26668</u> (PLUS-50™ II - 4.0 L (4.2 qt)) (WITH FILTER)

Change after every 200 Hrs/annually.



FUEL FILTER MIU800645 ( - DH610000) MIU803127 (DH610001 - )

Change after every 400 Hrs/Annually.



AIR FILTER
M131802 (PRIMARY)

M131803 (SECONDARY)

Change every 400 hrs. or anually.



JOHN DEERE SPECIAL PURPOSE GOLF AND TURF CUTTING UNIT GREASE TY6341 GREASE GUN TY26183

Change As Required.



OIL FILTER M806419

Change after every 400 Hrs.



**FUEL/ WATER SEPARATOR** 

AM881823 (SEPARATOR, (S/N: - DH610000))

M811032 (FILTER ELEMENT, S/N: - DH610000)

MIU802421 (FILTER ELEMENT, S/N:DH610001 -))

Change after every 400 Hrs.



FILTER PAK LVA21128

### TRANSMISSION/ HYDRAULIC

V - BELT



M801821 ( - DH610000) (LGTH = 986.03 mm, WIDTH = 12.7 mm, TK = 10.31 mm)

<u>LVU29586</u> (DH610001 - ) (LGTH = 1020 mm, WIDTH = 13.7 mm, TK = 9.5 mm)



### **ELECTRICAL**



KEY <u>LVA17264</u>



HEADLIGHT

LVA15865 (12 V) (NOT FOR USA AND CANADA, S/N: - 610000)



LVA14946 (12 V) (NOT FOR USA AND CANADA, S/N: 0610001-)



**ROTARY SWITCH** 

LVU29433 (S/N: - DH610000) LVA20451 (S/N: DH610001-)



BATTERY

TY26498 (12 V)

### **FUEL & AIR**



FILLER CAP TCU31996



MUFFLER

LVA14442

### **AXLE**

TIE ROD

LVA15994 (ASSEMBLY)

LVA15996 (LH)

LVA15995 (RH)



FRONT AXLE OIL

TY22000 (Low Viscosity Hy-Gard™) (3.2 L (3.4 qt))

Change after every 400 Hrs.

### TRANSMISSION/ HYDRAULIC



TRANSMISSION/HYDRAULIC OIL

TY22000 (Low Viscosity Hy-Gard™) (21 L (5.5 gal))

Change after every 50/400 Hrs.



**OIL FILTER** 

LVA14703 (SUCTION)

LVA16054 (TRANSMISSION)

Change after every 400 Hrs.

CLICK PART NUMBER TO BUY

