

REPLACEMENT PART GUIDE

9R Interim Tier 4 (IT4) Series Wheel Tractors(000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R FILTER OVERVIEW WITH SERVICE INTERVALS

ENGINE

DIESEL PARTICULATE FILTER (DPF)

[RE542183](#) (9360R)

[RE541836](#) (9410R, 9460R, 9510R, 9560R)

Replace within 250 hours after warning light indicators are illuminated. See your John Deere™ dealer or qualified service provider.

PRIMARY AIR FILTER

[RE312946](#)

SECONDARY AIR FILTER

[RE230985](#)

Replace annually and as required.

OIL FILTER

[RE509672](#) (9360R)

[RE572785](#) (9410R, 9460R, 9510R, 9560R)

Initial oil change is 500 hours, then every 500 hours or annually, whichever occurs first. The extended 500 hour interval is only allowed if using PLUS-50™ II oil with a John Deere™ filter and diesel fuel with sulfur content less than 15mg/kg (15ppm). If all the conditions are not met, change oil and filter at 250 hours of operation.

PRIMARY FUEL FILTER

[RE539465](#) (9360R, 9410R, 9460R, 9510R, 9560R) (IT4)

[DZ112918](#)

SECONDARY FUEL FILTER

[RE532952](#) (9410R, 9460R, 9510R, 9560R), (TIER 2)

[DZ112918](#)

Replace after every 500 hours or as indicated, whichever comes first.

FUEL WATER SEPARATOR FILTER (IF EQUIPPED)

[N378886](#)

Change after every 500 hours.



CAB

RECIRCULATION AIR FILTER

[RE291412](#)

[RE333569](#) (CARBON)

Replace after every 1000 hours or annually, whichever occurs first.

FRESH AIR FILTER

[RE284091](#)

[RE333567](#) (Carbon)

Replace after every 1000 hours or annually, whichever occurs first.

ENGINE

FUEL TANK VENT FILTER

[H216169](#) (2)

Replace after 1500 hours or 1 year, whichever occurs first.

HYDRAULICS

HYDRAULIC OIL FILTER

[RE577612](#) (QTY 2) (SINGLE REDUCTION AXLE) (DOUBLE REDUCTION AXLE) (QTY 3)

Replace every 1500 hours, or as required.

TRANSMISSION

OIL FILTER

[RE174130](#) (MST)

[RE577612](#) (PST)

Replace every 1500 hours.



JOHN DEERE

Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.

RX532586

Jan. 2024. Release Date.

CAPACITIES

9R Interim Tier 4 (IT4) Series Wheel Tractors (000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R

CAPACITIES (Approximate):

Fuel Tank

..... 1325 L (350 gal)

Cooling System Including Overflow Tank:

Cool-Gard™ II

9360R..... 42 L (11.1 gal)

9410R, 9460R, 9510R, 9560R..... 55 L (14.6 gal)

Crankcase including Filter:

Plus-50™ II

9360R..... 34 L (9.0 gal)

9410R, 9460R, 9510R, 9560R..... 48 L (12.7 gal)

24-Speed Transmission/Hydraulic Reservoir/SR Axles:

Hy-Gard™

9360R, 9410R, 9460R

Standard Flow..... 255.6 L (67.5 gal)

High Flow..... 259.4 L (68.5 gal)

Hydraulic Reservoir:

Hy-Gard™

Full - Hot..... 124.2 L (32.8 gal)

Full - Cold..... 101.9 L (26.9 gal)

Powershift Transmission/Hydraulic Reservoir:

Hy-Gard™

9360R, 9410R, 9460R – SR Axles

Standard Flow..... 282.1 L (74.5 gal)

9360R, 9410R, 9460R – SR Axles

High Flow..... 285.9 L (75.5 gal)

9510R, 9560R – DR Axles

Standard Flow..... 217.7 L (57.5 gal)

9510R, 9560R – DR Axles

High Flow..... 229.1 L (60.5 gal)



REPLACEMENT PART GUIDE

9R Interim Tier 4 (IT4) Series Wheel Tractors(000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R

ENGINE



TORSIONAL DAMPER

[TA20453](#) (9360R)
[RE584547](#) (9410R,9460R
9460R,9510R,9560R)



COMPRESSOR

[AL232177](#)



AUX DRIVE BELT

[R536677](#) (IT4)
[R533664](#) (T2)
[R329631](#) (9360R)



FAN DRIVE BELT

[R307304](#) (13.5L ENGINE)
[R568198](#) (9.0 L ENGINE)



RADATOR CAP

[RE312969](#)



ENGINE BLOCK HEATER

[RE15940](#) (220V)
[RE541654](#) (120V)
[RE42139](#) (9360R)



WATER PUMP

[DZ102107](#) (9360R)
[RE549117](#) (T2)
[DZ106318](#) (IT4)



BELT TENSIONER

[AN208610](#) (13.5 L ENGINE
T2 FAN DRIVE)
[RE243154](#) (9360R)
[DZ10469](#) (9410R,9460R,
9460R, 9510R,9560R) (T2, AUX)



ALTERNATOR

[RE555751](#)



STARTER

[RE539584](#) (9410R,9460R,
9460R,9510R,9560R)
[RE549229](#) (9360R)



FUEL INJECTION PUMP

[DZ124926](#) (9410R,9460R,
9460R,9510R,9560R)
[RE543262](#) (9360R)



CAB



WIPER BLADE

[AL153661](#) (FRONT AND
REAR)



MIRROR

[AT186760](#) (INTERNAL
REAR VIEW)
[RE322784](#) (EXTERNAL
REAR VIEW, MANUAL)
[RE307815](#) (EXTERNAL
REAR VIEW, POWER)



TECHNOLOGY MOUNTING SOLUTION

[RE317435](#) (MOUNTING
BRACKET)
[BRE10015](#) (CELL PHONE
MOUNT)
[BRE10255](#) (TABLET MOUNT)



GAS CYLINDERS

[RE261886](#) (REAR WINDOW)
[RE234992](#) (LH, DOOR)

HITCH AND SCV



HITCH MAINTENANCE

[R309355](#) (SWAY BLOCK RH)
[R304695](#) (SWAY BLOCK
WAR PLATE RH)
[R309356](#) (SWAY BLOCK LH)
[R304694](#) (SWAY BLOCK
WAR PLATE LH)
[RE334232](#) (HITCH POSITION
SENSOR)



SCV

[RE577560](#) (BREAKWAY
COUPLER)
[R186598](#) (SNAP RING)
[RE186600](#) (SEAL KIT)
[RE293262](#) (POWER BEYOND
COUPLER)



LIFT LINK PINS

[RE333939](#) (PIN)
[R106409](#) (DRAFT LINK
BALL STUD)
[BRE10331](#) (GREASEABLE
PIN KIT)

ENGINE



BATTERY

[TY25879E](#)

RX532586

Jan. 2024. Release Date.



JOHN DEERE

Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.

REPLACEMENT PARTS GUIDE

9R Interim Tier 4 (IT4) Series Wheel Tractors(000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R
WEAR PARTS

ENGINE



VARI-COOL™ FAN DRIVE

[RE572545](#) (DRIVEN, 9.0 L, IT4 / FT4)
(9370R)

[RE590285](#) (DRIVEN, 13.5 L, IT4 / FT4)
(9420R, 9470R, 9520R)



VARI-COOL™ FAN DRIVE

[RE578435](#) (DRIVER, 9.0 L, IT4 / FT4)
(9370R)

[RE588578](#) (DRIVER, 13.5 L, IT4 / FT4)
(9420R, 9470R, 9520R)



ENGINE

VARI-COOL™ FAN DRIVE

[R568198](#) (V-BELT, VARIABLE SPEED)
(9370R)

[R300399](#) (V-BELT, VARIABLE SPEED)
(9420R, 9470R, 9520R)



VARI-COOL™ FAN DRIVE

[R569237](#) (BELT GAUGE TOOL)

