


New Features:

File Manager USB Indicator – When a USB is connected to the StarFire™ 6000 and properly recognized, a Green USB icon will appear on the File Manager Indicator.



External Interference Detection – A new DTC has been implemented to help troubleshoot with external interference sources. DTC 841.31 will become active if High or Low band AGC (DA 63 and 64) and GPS Signal % is not in normal range for more than 5 minutes. The DTC will be cleared after 30 minutes if the interference source is no longer present.

RTK-X Checkbox – In the setup pages, there is now a checkbox to enable/disable RTK-X, if customers are experiencing issues with RTK-X they now have the option to disable it. By default, RTK-X will always be enabled.



Release Notice

These are software release notes for StarFire™ products. Release Notes can be found on www.stellarsupport.com. Note: Your use of the software is governed by the End User License Agreement included with the software.

Copyright © 1996-2018 Deere & Company